



Spare part	Spare part description	Contained in
RA36	EBR barrier cover with flashing diffuser	EBR1, EBR2
RA120	Spare part chest for EBR barrier	EBR1, EBR2
RA121	Spare part holder for EBR barrier	EBR1, EBR2
RA122	Spring tie-rod group for EBR	EBR1, EBR2
RA123	Spring holder group for EBR	EBR1, EBR2
RA124	Output shaft group for EBR	EBR1, EBR2
RA125	Pole shaft group for EBR	EBR1, EBR2
RA126	Pole shaft holder for EBR	EBR1, EBR2
RA127	Closing stop group with cabling for EBR	EBR1, EBR2
RA128	Two caps pole shaft stop for EBR	EBR1, EBR2
RA129	Accessories for control panel+holder for EBR	EBR1, EBR2
RA130	Releasing key for EBR	EBR1, EBR2
RA131	Lampholder with cabling for EBR	EBR1, EBR2
RMEBR1	Replacement gearmotor for barrier EBR1	EBR1
RMEBR2	Replacement gearmotor for barrier EBR2	EBR2
EBRB	Fixing plate for EBR	EBR1, EBR2