



Surface mounting components: By-alarm - Configuration interface

01725

Safety / By-alarm Plus / Surface mounting components / Non-modular components

By-alarm - Configuration interface

Interfaces and cables that enable the installer to configure the By-alarm system completely

9 - Discontinued



- [Multilanguage instructions sheet \(1160 kb\)](#)
- [Anweisungsblatt \(765 kb\)](#)